

FIBERGLASS RESIN

DIRECTIONS:

Mix Polyester Resin and Hardener using 12 drops of Hardener per ounce of Resin. 11cc per quart and 40cc per gallon. At 77 °F (25 °C) Resin will begin to gel in approximately 1/2 hour. In warm temperatures 90 °F (32 °C), reduce Hardener content approximately 50%. At lower temperatures 60 °F (18 °C), increase hardener content by approximately 100%. Use 4 fl. oz. of hardener, resin mixture per one sq. ft. of fiberglass mat or 2.5 fl. oz. per one sq. ft. of fiberglass cloth or tape.

Caution:

Keep from heat or open flame. Avoid contact with skin, eyes or mucous membranes. In case of contact, flush thoroughly with water. For eyes, get prompt medical attention. If swallowed, give large quantities of water or milk. Get medical attention immediately. Keep out of reach of children.

Contains: Methyl Ethyl Ketone Peroxide

(S-235)



"Your Hometown Taxidermy Supply Store"