

Artificial Splash Molds

DIRECTIONS

1) Prepare splash molds by lightly spraying with either a non-silicone based aerosol release agent (stock # S-254) or a silicone based release agent, (stock # S-255) whichever you prefer. Follow the directions on the back of the can for use.

2) Mix scenery resin (stock # S-259) as per instructions on the container, catalyzing the resin at minimum amount prescribed. When combining resin and catalyst, stir slowly without lifting stir stick out of the container. This will minimize the number of air bubbles. If air bubbles do occur, allow mixture to set for a few minutes before pouring, so that bubbles have time to dissipate. Now, pour the scenery resin into the splash molds.

3) Allow resin to set completely, then carefully de-mold splashes. Grind or sand off any flanges or burrs.

4) There are many methods to use with splash molds. The sky is the limit when using your imagination! For example:

Cut a piece of 1/4" clear Plexiglas and attach it to your base. Glue splashes onto the Plexiglas with catalyzed scenery resin. Sanded areas, fingerprints and seams can be covered up by pouring catalyzing resin over them.



RESEARCH MANNIKINS

1-800-826-0654 • (541) 451-1538 OFFICE • (541) 451-5455 FAX

“Your Hometown Taxidermy Supply Store”